

Planck default keymap - QMK Firmware

Main typing layers [Qwerty, Lower, Raise]

Tab ~	1 Q !	2 W @	3 E #	4 R \$	5 T %	6 Y ^	7 U &	8 I *	9 O [0 P]	Backsp
Del Esc	F1 A	F2 S	F3 D	F4 F	F5 G	F6 H	- J _	= K +	[L {] ; }	'
Shift	F7 Z	F8 X	F9 C	F10 V	F11 B	F12 N	M ,	.	PG UP HOME	PG DN END	Enter
Fn*	Ctrl	Alt	OS	Lower	Space	Space	Raise	Next Left	Vol - Down	Vol + Up	Play Right

* Fn presses shift and cycles through the backlight settings

Adjust layer [Lower + Raise together]

	Reset										Delete
			Audio On*	Audio Off*	Alt/OS Mac*	Alt/OS Win*	Qwerty*	Colemak*	Dvorak*	Plover	
	Cycle Voices Back	Cycle Voices Forw	Music Mode On	Music Mode Off							
				Lower				Raise			

* These options are persistent over keyboard power loss and stored in the EEPROM (you'll only need to set them once)

For more information on the firmware, visit https://github.com/qmk/qmk_firmware. The default keymap evolves over time, and the one in the repo may be slightly different than what is shown here - for the Massdrop that started in March 2017, this is the keymap that came programmed onto the PCBs, and can be used as a typing reference.

Many keys on the Lower/Raise layers were left blank for customising, so consider adjusting things to your liking! Compiling instructions are on the repo's wiki.