

2. Announce

Attention

When with the electric power the driving replenishment link of time burn the iron to lead the temperature to compare the Celsius 200 the high is to 480 degree.

Be used by possibility is according to that burn or spark to take, please strictly under the item obedient to:


- *Don't want the touch and burn the head metals of the iron neighborhood the part.
- *Near of the method of using burn the brunt quality of the iron head the thing and inside does not want.
- *Plant of industry circular others, and combustion the iron head is very hot, and may cause the danger of trouble.
- *Take a resting the hour or completing work impressing should turn off the power supply.
- *While replacing the spare parts or device to burn the iron head, should turn off the power supply, and wait for to burn the iron head to cool off the general temperature.

In order not to the usage electricity burn the set, and keep the safety of the homeward environment, and should obey the following items:

- *Don't want to use the coal iron the head to proceed the work of burning to connect the excluding.
- *Don't wanting will burn to iron to knock or touch the work set with remaining that the clearance destroy by fire to leave, and this act the possibility to damage to burn the iron seriously.
- *Don't want to give or get an electric shock to burn the set from the changes, or hand wetness the hour also can't use the electricity to burn the set.
- *While burning to connect can emit smoke, work to should have the good and well ventilated facilities.
- *While use electricity to burn the set, must not make any possible disservice or damage the object activity.

3. Equip with use the GAOYUE 936、936E、936B、936A+

A. Burn the iron

 Attention: The sponge can squeeze the object, and run into the water to can become big, usage sponge, first the wet water is again the bear. Would otherwise damage to burn the iron head.